





### The cooler fan speed levels provided are for reference use only. Please refer to the motherboard BIOS to verify actual fan speed levels.

### The followings are not covered by the warranty :

- 1. Use the product incorrectly or in a manner other than the designed purpose. 2. Nonobservance of the proper operation. ( e.g. over-clocking )
- 3. Malfunction due to interference from other devices.
- 4. Unauthorized modification of the product.
- 5. Malfunction due to unfit specifications on Motherboard.
- 6. Malfunction arising from casualties ( earthquake, thunder, fire, and flood ).

## Features

- 1. Universal design, supports LGA775 & AMD K8 / AM2 platform.
- 2. Curve design combines CPU and MOSFEAT cooling together.
- 3. 9CM silent fan with PWM function, highest fan speed can reach 2300RPM.
- 4. Highly heat conducting heat pipe, provides extreme cooling performance.
- 5. Pure copper base with aluminum fin, extra large heat dissipation area allows heat been carried away faster. 6. Hassle-free installation.

## Specification

( )

Dimension : 102 x 122 x 139 mm Fan Dimension : 90 x 90 x 25 mm Heat Pipe : 3 Base Material: Copper Fin Material : Aluminum Rated Voltage : 12 V Rated Current : 0.2 Amp Fan Speed : 2,300 rpm Noise Level : 25dBA Bearing Type : EBR Fan Life Expectancy : 30,000 hr

## Compatible CPU

or computer-related devices.

in this manual.

Intel<sup>®</sup> Core<sup>™</sup> 2 Extreme Processor Series Intel<sup>®</sup> Core<sup>™</sup> 2 Ouad Processor Series Intel<sup>®</sup> Core<sup>™</sup> 2 Duo Processor Series Intel<sup>®</sup> Pentium<sup>®</sup> Extreme Edition Series Intel<sup>®</sup> Pentium<sup>®</sup> D. Processor Series Intel® Pentium® 4 Processor Series (LGA775) AMD AM2 AMD Athlon<sup>™</sup> FX Series AMD Athlon™ 64x2 Series AMD Athlon<sup>™</sup> 64 Series AMD Sempron Series

7. The product's warranty label has been removed or damaged.

8. The devices inside, including power supply, hard disk, CD-ROM drive,

motherboard, cooler, etc, are not detached from the chassis prior to the

transportation of the computer product, resulting in damage to the cooler

9. Any damage caused by nonobservance of the installation instruction contained

### Accessories









LGA775 Bracket





# LGA 775 Platform Installation

## STEP 1



Caution Before installation, please turn off the power, unplug the power cord, and be sure to remove the sticker from the bottom of the cooler unit.



Place the 775 bracket between the copper base and the cooler unit. Align the holes of the bracket with the holes of the copper base. Secure the 775 bracket with supplied bracket screws. Make sure the screws are evenly and firmly fastened.

## STEP 3



Before installation, please make sure the pin is on the right direction. (as Figure A)



To remove the cooler, turn the four pins to the removing direction and pull them up.(as Figure B)



Alian the pin of the cooler with the hole of the CPU on the the pin diagonally. are firmly secured.



Plug the 4-pin connector of the cooler into the motherboard's CPU fan socket.



motherboard and push down Please make sure the four pins

# AMD K8 / AM2 Platform Installation

Apply some thermal grease on

## STEP 1



autior Before installation, please turn off the power, unplug the power cord, and be sure to remove the sticker from the ottom of the cooler unit



STEP 2

Place the AM2/K8 Bracket between the copper base and the cooler unit. Align the holes of the bracket with the holes of the copper base. Secure the AM2/K8 Bracket with supplied bracket screws. Make sure the screws are evenly and firmly fastened.



Lock the tab on the other side of AMD K8 / AM2 clip in the salient point of the CPU cooler bracket: push down and secure the bar on . the clip firmly.







Thermal grease



Lock the tab on one side of AMD

the CPU properly.





CPU fan socket.



Plug the 4-pin connector of the cooler into the motherboard's



STEP 4

