



MODEL: MO-1210

Digital DC Milliohm Meter

OPERATING INSTRUCTION

Index

1. Introduction	1
1-1.Brief	1
1-2.Features	1
1-3.Specification	1
2. Machine	4
2-1.Panel	4
2-2.LCD	4
3. Operation	5
3-1.Overrange Indication.....	5
3-2.Battery Voltage	5
3-3.Automatic measurement.....	5
4. Function and configuration.....	5
4-1. Common Test function.....	5
4-2. Comparison Selection	6
4-3. Temperature measurement	7
4-4. Temperature Compensation	8
4-5. Recall stored records	9
4-6. LCD back lit	9
5.Measuring method	9
5-1. four wires measurement.....	9
5-2. Temperature measurement.....	11
6.Maintenance	14
6-1. Replace battery	14
6-2. Cleaning	14
7.Accessories	14

SAFETY PRECAUTION AND SYMBOL



THIS METER IS NOT APPLICABLE FOR CAT II,III and IV

BELOW SYMBOLS MAY APPEAR IN THIS MANUAL OR THE METER



HIGH VOLTAGE HAZARD



REFERENCE TO MANUAL



PROTECTED CONDUCTOR TERMINAL



EARTHING TERMINAL

1. Product Introduction

1-1 Introduction

MO-1210 is a DC milli-ohm meter with high accuracy adequate for low resistance measurement in switches, electric relay, PCBs, connectors and relevant equipments.

With PT-100 temperature probe, the meter can control measuring impedance to accommodate environment changes.

The meter can be used to measure contact resistance in switches, relays, PCBs, cables, connectors, and component testing in resistors, motors, fuses, hot resistance wires. It can also be used in warehousing inspection, quality check and conductivity evaluation in product design.

1-2 Features

- 2000 counts
- measure range $10 \mu \Omega \sim 200k \Omega$
- 0.3% accuracy
- temperature compensation and measurement
- four terminal kelvin method
- PASS/FAIL alarm settings
- sample rate 3 times per second

1-3 Specification


Specification is designed and used under following conditions:

- calibrated once a year
- ambient temperature $18^{\circ}\text{C} \sim 28^{\circ}\text{C}$ ($64.4^{\circ}\text{F} \sim 82.4^{\circ}\text{F}$)
- relative humidity $< 80\% \text{ RH}$
- indication of accuracy: $\pm(\% + \text{digits})$

1.MEASUREMENT OF RESISTANCE				
2000 counts (rate: 3 times/seconds)				
Range	Resolution	Test current	Accuracy	Open circuit Voltage
20m	10 μ	250mA	0.5%+5	5V
200m	100 μ	250mA	0.3%+6	
2	1m	100mA	0.3%+3	
20	10m	50mA	0.3%+2	
200	100m	5mA	0.3%+2	
2k	1	500 μ A	0.3%+2	
20k	10	50 μ A	2%+2	
200k	100	5 μ A	2%+2	
Accuracy of 2000counts (rate : 3times/sec.)	± 5 count			
Measurement	Four wires Kelvin method			
Overrange	OL			
Max. rated voltage	50VpDC			
Records	500 sets			
Buzzer	NON,PASS,FAIL			


2. Measurement of Temperature		
Temperature		Pt resistor
Rnage	Resolution	Accuracy(Sample :2times/ sec.)
- 9.9°C ~ 100°C	0.1°C	± 1%±1°C
3. Temperature Compensation		
Temp. Compensation Range	0.0°C~40.0°C	
Reference Temp. Range	0°C~90°C	
Heat factor Range	± 9999ppm	
Temp. Range	Accuracy of temp. compensation 3930ppm/copper wire	
<p>* Other configured-temperature factor must calculate separately in accordance with different conditions.</p> <p>* In case temperature factor environment is over a normal operation range from configured temperature, the compensated reading may vary greatly.</p>		
4. Environment		
Operating Environment	Indoor use, altitude<2000m Ambient temp. 0.0°C~40.0°C Max. Relative humidity80%RH Pollution deg. 2	
Storage temp.	- 10°C ~ 50°C	
5. Other		
Power	8x1.5VAA	
Accessories	Test wirex1 , Manualx1 , Temperature sensor x1	

2 Introduction of Machine



2-1 Panel

- 1) Range rotary
- 2) Up/Down button for digit selection 图2-1
- 3) Esc button for cancellation operation
- 4) SET/RCL button short press to configure parameters, long press to review stored data
- 5) ENTER/SAVE button
- 6) FN/back lit button short press for function selection, long press for back lit On/off
- 7) temperature probe connector
- 8) LCD
- 9) measuring terminals
- 10) current source terminals



2-2 LCD

- 1) Number of records
- 2) Maximum numbers of stored records
- 3) low battery symbol
- 4) Message indication
- 5) Setting status symbol
- 6) Records reviewing symbol
- 7) Main display area
- 8) sub display area

3- Operation instruction

3-1 Over range indication

If the input resistor exceeds the selected range, LCD shows OL.

3-2 Battery voltage acknowledgement

If low battery warning symbol is on when measuring, please stop measurement and replace batteries. The meter will not measure until the batteries are replaced.

3-3 Automatic measurement

There is no Test button in this meter. The meter starts measurement if proper range is selected and connection is correct.

4 Function introduction and configuration.

Testing conditions must be configured properly before measurement. Settings is shown in sub display area. Press FN button to switch configuration.

4-1 Common test function (R):

As soon as the meter is powered on, the meter shows common test function below. Now it is ready for measurement.

N003		
R	0.L mΩ	RK=0000 ^{mΩ}

Fig. 4-1 common test function interface

Parameter settings:

Rk: Residual resistors of test wires. Test and save Rk of testing wires before measurement. The meter will automatically remove Rk before showing final readings to provide a more accurate result.

Configuration procedures of Rk:

- Select measuring range
- Press "SET/RCL" button to enter Rk settings with flickering "SET" symbol shown on LCD as below.




fig.4-2 Rk configuration □ Rk in sub display is flickering

- Connect the test wires shorted together to automatic measure Rk.
- Press "ENTER/SAVE" to save the measured Rk and back to common measuring mode.

Press "ESC" button to discard savings and back to common measuring mode.

IMPORTANT NOTE: Rk value is deleted in case the range of measurement is changed or the power is off.

4-2 Comparison Selection function (CR):

As below shown, press "FN/☀" button to enter comparison measurement.




Fig.4-3 Interface of Comparison Selection function

In accordance with the input up/low limit, the meter shows PASS/FAIL to the measured resistance on LCD with buzzer.

For instance,
 Standard value: 100.0
 upper limit: 110.0
 low limit: 80.0

PASS/FAIL indication shows if the measured resistance is as below:

- 109.0 measured, PASS symbol on
- 120.0 measured, FAIL symbol on
- 70.0 measured, FAIL symbol on

Parameters to configure:

Rk: residual resistance of test lines

Hi/Lo: up/low limit

bp: buzzer has three conditions optional. "PASS" means buzzer will sound when the measured resistance is passed. "FAIL" means buzzer will sound when measured resistance is failed in the test. "NON" means buzzer will not work.

Operating instruction:

Rk configuration , please refer to "Common test function" to complete the setting of Rk.

HI/LO, bp settings:

- In Comparison function mode, press "SET/RCL" button to light on configuration symbol "set" as below Fig.4-4 shown, short press "SET/RCL" to switch between configurable parameters.




Fig.4-4 Configuration of Comparison Selection. The selected parameter to configure is flickering.

- Press ▲ or ▼ button to change value.

- Press "ENTER/SAVE" to save the setting and switch to next parameter. Press "ESC" to discard changes and return to Comparison function mode (fig.4-3).

- As soon as all parameters are well configured and saved, press "ESC" to complete configuration and return to Comparison function mode (fig.4-3).

Important note: HI/LO values and bp buzzer are not erased if test mode is changed, however, need to be configured again if resistance range is changed or power is off.

Buzzer does not sound if the meter is not working in Comparison function mode.

4-3 Temperature measurement mode(T):

(1) Connect the temperature probe to panel connector (Fig.4-5)




Fig.4-5 Connection of temperature sensor and machine

(2) Press "FN/☀" button to enter temperature measurement function. (Fig.4-6)



Fig.4-6 Temperature measurement

- (3) Temperature measurement can be used in every range.
- (4) The measured temperature is directly shown on LCD main display area.

4-4 Function of temperature compensation measurement(TC)

Correct impedance of the object can be calculated by measured ambient temperature, input material temperature factor and input target temperature.

- (1) Connect temperature sensor properly to connector of meter as fig.4-5.
- (2) Press "FN/☀" button to enter temperature compensation measurement mode (fig. 4-7). Measured reading is shown on main display area. Rc is the calculated impedance value of the measured object.




Fig.4-7 Temperature Compensation Measurement

Parameters to configure:

Rk: Residual resistor of test wire.

K: Material correction factor

Mt: target temperature (expected temperature)

Operating instruction:

Rk configuration , please refer to "Common test function" to complete the setting of Rk.

Configuration of K, Mt:

- In temperature compensation mode, press "SET/RCL" button to enter configuration with set symbol on (Fig. 4-8). Short press "SET/RCL" to switch between parameters.




图4-8温度补偿测量功能设定画面，当前可设定的参数呈闪动状态

- Press ▲ ▼ buttons to change value.

- Press "ENTER/SAVE" to save the setting and switch to next parameter. Press "ESC" to discard changes and return to Temperature measurement mode (fig.4-7).

- As soon as all parameters are well configured and saved, press "ESC" to complete configuration and return to Temperature measurement mode (fig.4-7).

Important note: The input K/Mt values are not erased if function mode is changed. The input values are deleted if the meter is powered off.

4-5 Recall the stored records

Long press "SET/RCL" button to review all stored records. Press up/down button to browse by number. Total records is 500 units with number **N001**. Press "ENTER/SAVE" button to delete the record by selection between **DL_ONE** to delete current record and "DL_ALL" to delete all records. Press "ENTER/SAVE" button again to confirm deletion of one or all.

In case **MEM EMPTY** is flickering on LCD, there is no record stored in the meter. If **MEM FULL** is shown on LCD, the memories are full.

4-6 Backlit

Long press "FN/☀" to turn on backlit for 30 seconds. During this period, long press "FN/☀" again to turn off backlit if required.

5 Connection of test leads

5-1 Four wires measurement method

Four wires measurement method can remove residual resistance R_k to result a more accurate reading. Please see Fig. 5-1 for connection.




Fig. 5-1

Principle

1- Traditional two wires measurement method, as fig.5-2, are interfered by residual resistance R_k . The measured reading is:

$$\frac{V}{I} = r_1 + R + r_2$$




Fig. 5-2

2- Four wires measurement method works with high input impedance of voltage meter.

There is no voltage drop and current through on r_3 and r_4 . (see fig. 5-3) Hence, voltage can measure resistance accurately. The measured reading is:

$$R = \frac{V}{I}$$




Fig. 5-3

5-2 Temperature measurement

(1) Reference temperature

International Temperature Standard (ITS) is based on fix point and relevant temperature of 17 types of materials in Table 5-1.

Materials	Type	Temperature	
		K	$^{\circ}\text{C}$
(H ₂) hydrogen	3 phase point	13.8033	-259.3467
(Ne) neon			
(O ₂) oxygen			
(Ar) argon			
(Hg) hydrargyrum	3 phase point	234.325	-38.8344
(H ₂ O) water	3 phase point		
(Ga) gallium	Melting point	273.16	+0.01
(In) indium	Freezing point	302.9146	29.7646
(Sn) tin	Freezing point	505.078	231.928
(Zn) zinc			
(Al) aluminum			
(Ag) silver			
(Au) gold			
		1234.93	961.78
		1337.33	1064.18

Note:

(1) unit of temperature
 thermodynamic temperature: T
 degree Kelvin: K

(2) thermometric scale
 centigrade degree : °C
 rankine temperature : °R
 degree Fahrenheit: °F

(2) Sensor of temperature measurement
 Impedance temperature sensor RTD converts temperature to electric signal.

Characteristic reference is as table 5-2.

Table 5-2

	Characteristic	Description
1.	Accuracy	Highly accurate
2.	Resolution	0.1~1.0 °C
3.	Response time	Slow
4.	Self Heating	Yes
5.	Long term stability	Good
6.	Output curve	Approx. 0.4 ohm/°C, nearly linear

(3) Optional Pt resistor temperature sensor
 This sensor conforms to DIN43760:1968, three wires measurement method.
 Relation between temperature and impedance is as formula below:

$$R_{RTD} = R_0 [1 + AT + BT^2 + CT^3(T-100)]$$

Here:

RRTD is the calculated impedance of RTD
 R0 is the known impedance of RTD in temperature 0°C
 T is temperature unit °C

$$A = \alpha [1 + (\delta/100)]$$

$$B = -\alpha(\delta)(10^{-4})$$

$$C = -\alpha(\beta)(10^{-8})$$

Values of Alpha, beta and delta please see table 5-3 below

Table 5-3

Type	Standard	Alpha	Beta	Delta	Ohms in 0°C
PT-100	ITS90	0.003850	0.10863	1.49990	100 Ω

For instance:

Calculate impedance value of PT-100 RTD in temperature 100°C. Alpha, beta and delta values of R0 (the ohms value in temperature 0°C) applied in calculation of PT-100 RTD are:

T=100°C

R0 (the ohms value in temperature 0°C)=100ohms

Alpha=0.003850

Beta=0.10863

Delta=1.49990

A,B and C values are calculated in accordance with below reference:

A=0.00391


B=5.77e-7

C=4.18e-12

Then, RTD in temperature 100°C (R100) can be calculated below:

$$\begin{aligned} R_{100} &= R_0 [1 + AT + BT^2 + CT^3(T-100)] \\ &= 100 \{ 1 + [(0.00391)(100) + [(-5.77e-7)(100^2) + [(-4.18E-12)(100^3)(100-100)]]] \} \\ &= 100 [1 + 0.391 + (-0.006) + 0] \\ &= 100 (1.385) \\ &= 138.5 \Omega \end{aligned}$$

(4) Temperature sensing terminal



Wire A connects a fix terminal of sensor, Wire B and C connect to another two terminals. Wire B and C can be exchanged. If extension wire of temperature sensor is required, the length and specification of three wires must be consistent.

6 Maintenance

6-1 Replace battery

- Do not open battery cover if the housing of meter is moist.
- DO not replace batteries during measurement. To avoid electric shock, please turn of the meter and disconnect test wires.
- Open back batteries cover and replace batteries.

Note: All of stored records are deleted after the batteries are replaced.

6-2 Cleaning

- To keep the meter clean, please use wet cloth with detergent to clean meter. Do not use scrub agent and solvent.

7 Accessories

- a) Specific gold-plating test wire x1
- b) Pt temperaturesensor x1
- c) AA 1.5V batteries x8
- d) carry case x1
- e) operating instruction x1

ICEL *manaus*
www.icel-manaus.com.br
Janeiro 2017