Autonics

Threaded/Side Mounting Photoelectric Sensor BH SERIES

INSTRUCTION







Thank you for choosing our Autonics product.

Please read the following safety considerations before use.

■ Safety Considerations

- %Please observe all safety considerations for safe and proper product operation to avoid hazards
- ★ Symbol represents caution due to special circumstances in which hazards may occur.

Marning Failure to follow these instructions may result in serious injury or death. ↑ Caution Failure to follow these instructions may result in personal injury or product damage.


- Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss. (e.g. nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime/disaster
- ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime/disaster prevention devices, etc.)
 Failure to follow this instruction may result in personal injury, economic loss or fire.

 2. Do not use the unit in the place where flammable/explosive/corrosive gas, high humidity, direct sunlight, radiant heat, vibration, impact, or salinity may be present.
 Failure to follow this instruction may result in explosion or fire.

 3. Do not disassemble or modify the unit.

- Do not disassemble or modify the unit.
 Failure to follow this instruction may result in fire.
 Do not connect, repair, or inspect the unit while connected to a power source.
 Failure to follow this instruction may result in fire.
 Check 'Connections' before wiring.
 Failure to follow this instruction may result in fire.

⚠ Caution



The above specifications are subject to change and some models may be discording

Ø4 2 1m

M18 fixing nut

X Be sure to follow cautions written in the instruction manual and the technical descriptions

Fixing cap

Ø25

Ø16.9

Model

/lodel	Sensing distance	Sensing type	Power supply	Output		
3H20M-TDT	20m	Through-beam type				
3H4M-PDT	4m	Retroreflective type (built-in polarized filter)	172=2Δ\/)(:	Transistor output (NPN/PNP)		
BH1M-DDT	1m	Diffuse reflective type				
3H300-DDT	300mm	Diliuse reliective type			-	

Specifications

Model		BH20M-TDT	BH4M-PDT	BH1M-DDT	BH300-DDT		
Sensing type		Through-beam	Retroreflective (built-in polarized filter)	Diffuse reflective			
Sensing	distance	20m	4m ^{×1}	1m ^{**2}	300mm ^{**3}		
Sensing target		Opaque material over Ø20mm	Opaque material over Ø75mm	_			
Hysteres	is	— Max. 20% at sensing distance					
Respons		Max. 1ms					
Power su	apply	12-24VDC ±10% (ripple P-P: max. 10%)					
Current consumption		Emitter/Receiver : max. 20mA	Max. 30mA	Max. 35mA	Max. 30mA		
Light sou		Red LED (660nm)	Red LED (660nm)	Infrared LED (850nm)	Red LED (660nm)		
Sensitivity adjustment		Sensitivity adjuster					
Operation	n mode	Light ON / Dark ON selectable by switch					
Control output		NPN / PNP open collector simultaneous 2 output Load voltage: max. 26.4VDC					
Protection circuit		Interference prevention function (except through-beam type), Power reverse polarity protection circuit, Output short over current protection circuit					
Indicator		Operation indicator: red LED, Stability indicator: green LED (emitter of through-beam type's power indicator: green)					
Connecti		Cable type					
Insulation resistance		Over 20MΩ (at 500VDC megger)					
Dielectric strength		1,000VAC 50/60Hz for 1 minute					
Vibration		1.5mm amplitude at frequency of 10 to 55Hz (for 1 min) in each X, Y, Z direction for 2 hours					
Shock		500m/s² (approx. 50G) in X, Y, Z direction for 3 times					
		Sunlight: max. 11,000lx, Incandescent lamp: max. 3,000lx (receiver illumination) 2-25 to 55°C, storage: -40 to 70°C					
		35 to 85%RH, storage: 35 to 85%RH					
Protection structure		IP67 (IEC standard)					
Material		Case: polycarbonates, LED indicator: polycarbonates, sensing part: polymethyl methacrylate acrylic					
Cable		Ø4mm, 4-wire, 2.1m (emitter of through-beam type: Ø4mm, 2-wire, 2.1m) (AWG24, core diameter: 0.08mm, number of cores: 40, insulator out diameter: Ø1.03mm)					
Acce- ssory	Common	Adjustment crewdriver, fixing racket, M18 fixing hat: 1, fixing bracket, M18 fixing nut: 1, fixing bracket, M18 fixing nut: 1, fixing cap: 1, M3 bolt: 2, M3 nut: 2					
	Individual	_	Reflector (MS-2A)	<u> </u>			
Approval		(€, :(\h):s deres	. , ,				
Weight ^{**5}		Approx. 190g (approx. 120g)	Approx. 140g (approx. 60g)	Approx. 130g (appr	ox. 60g)		

X1: The sensing distance is specified with using the MS-2A reflector.

The distance between the sensor and the reflector should be set over 0.1m. When using reflective tapes, the reflectivity will vary by the size of the tape.


Please refer to the catalog or web site.

X2: Non-glossy white paper 300×300mm.X4: UL approved surrounding air temperature 40°C X3: Non-glossy white paper 100×100mm


%5: The weight includes packaging. The weight in parenthesis is for unit only.

%The temperature or humidity mentioned in Environment indicates a non freezing or condensation


■ Control Output Diagram



XIf short-circuit the control output terminal or supply current over the rated specification normal control signal is not output due to the output short over current protection circuit



MST-200-2



Installation and Sensitivity Adjustment


© For mounting Please use M18 fixing nut or M3 bolt and nut to mount the sensor, and make sure that the tightening

(white) PNP output

orque is under 0.5N·m When using the reflective type photoelectric sensors closely over three units, it may result in malfunction due to mutual interference. When using the through-beam type photoelectric sensors closely over two units, it may result in malfunction due to mutual interference. *Exercise caution. Do not apply excessive impact to the unit or bend the cable section.

The inside unit may be wet. M18 Fixing Nut M18 Fixing Nu M3 Nut

Operation mode selecting



Optical axis adjustment

Through-beam type

(white) PNP output

Set the emitter and the receiver facing each other and adjust these up-down, right-left after to check the point operating the stability indicator. Fix the emitter and the receiver at the center of the point


Retroreflective type

Set the photoelectric sensor and the reflector (MS-2A) or reflective tape facing each other and adjust the reflector up down, right left after to check the point operating the stability indicator. Make sure that the sensing side of the sensor is parallel with the reflector.

Diffuse reflective type

After place a sensing target, fix it in the middle of position where the stability indicator operates adjusting the sensor to up-down, right-left. Make sure that the sensing side of the sensor is parallel with the surface of each sensing target.

Sensitivity adjustment



Moves up-down


Moves right-let

Order | Sensitivity setting | Descriptions From Light ON status, turn the sensitivity setting adjuster slowly to the right from min. sensitivity (-) and check the position where operation indicator turns on (A).

From Dark ON status, turn the sensitivity setting adjuster further right and check the position where the operation indicator turns on (B). Turn the adjuster left and check the position where the operation indicator turns off (C). XIf the operation indicator does not turn on at max. sensitivity (+), the maximum sensitivity setting is set at position (C).

Set the adjuster at the center position between (A) and (C) for optimal sensitivity. Also, check if the stability indicator turns off with or without the sensing target.

If it does not turn off, please review the operation mode again, as sensitivity may be unstable.




XPlease set the sensitivity setting adjuster is executed in stable Light ON area and the reliability of environment (temperature, supply, dust etc.) is increased after the mounting it in a stable area. XIt may cause breakdown when the sensitivity setting adjuster or the operation mode selection switch

Operation Mode


Operation mode	Light ON		Dark ON			
Receiver operation	Received light		Received light			
	Interrupted light		Interrupted light			
Operation indicator	ON		ON			
(red LED)	OFF		OFF			
Transistor output	ON		ON			
(NPN/PNP)	OFF		OFF			

Operation Timing Diagram

○ Through-beam type



Retroreflective type / Diffuse reflective type



*The waveforms of "Operation indicator" and "Transistor output" are for Light ON, The waveforms are reversed for Dark ON.

Cautions during Use

- 1. Follow instructions in 'Cautions during Use'. Otherwise, it may cause unexpected accidents.
- 2. When connecting a DC relay or other inductive load to the output, remove surge by using diodes or varistors.
- . Use the product, 0.5 sec after supplying power.
- When using separate power supply for the sensor and load, supply power to sensor first.

 12-24VDC power supply should be insulated and limited voltage/current or Class 2, SELV power
- supply device. . Wire as short as possible and keep away from high voltage lines or power lines, to prevent inductive
- . When using switching mode power supply to supply the power, ground F.G. terminal and connect a
- condenser between 0V and F.G. terminal to remove noise . When using sensor with the equipment which generates noise (switching regulator, inverter, servo
- motor, etc.), ground F.G. terminal of the equipment
- . This unit may be used in the following environments

■ Temperature Controller

- ①Indoors (UL Type 1 Enclosure)
- ②Altitude max. 2,000m
- ③Pollution degree 3
- (4) Installation category II

Major Products



- Fiber Optic Sensor

- itching Mode Power \$
- ntrol Switches/Lamps/Buzzers O Terminal Blocks & Cables
- epper Motors/Drivers/Motion Con aphic/Logic Panels

Autonics Corporation http://www.autonics.com HEADQUARTERS Korea, 48002 TEL: 82-51-519-3232

DRW160440AG