

KPNP

Slim Body Automatic Sensitivity Setting Fiber Sensor



Compact size with advanced sensing technology



Thickness: 10 mm

Just 10 mm thick. Even a number of FX-7 amplifiers save space.



 $W10 \times H31.5 \times D59 mm$

Sensitivity : 8 times higher than before

The FX-7 amplifier performs precise and accurate sensing 8 times greater than a conventional model. It can be used not only to detect the presence of an object, but also to discriminate color, or find a thin film overlap. Complicated and sophisticated application needs are relied on the FX-7. The FX-7 series also provides the green LED amplifier that is eligible for applications much delicate.



Easily detects translucent film overlap.

Long sensing range

The standard M4 fiber offers the sensing range of 600 mm.



Reflective type

M6 standard • long sensing range fiber FD-B8 📲 💶 🛶 160 mm

Sensitivity shift

If either one of the Light state or the Dark state is unstable but the other is stationary, the threshold level can be shifted from the center between the set ON and OFF levels to the stationary side.

Automatic sensitivity setting

Anyone can set on optimum sensitivity by just pressing buttons. Even if its power is turned off, the EEPROM memory saves your set sensitivity.

Press the 'ON' button with an object -



Press the 'OFF' button with no object



Stability margin indication

The number of blinks of the stability indicator represents the stability margin that you have set the sensitivity.

Number of blinks	0	1	2	3	4	5
Margin (%) (Margin near by threshold level)	Under 15	15 to 30	30 to 45	45 to 60	60 to 75	Over 75



APPLICATIONS

Detecting wafer

The FD-L42 convergent sensing fiber securely detects a wafer without any affection of color or glossiness of the surface.



Detecting clock hands

The FD-EG1 fiber and the FX-MR3 spot lens produce the smallest projection area of 0.3 mm diameter.



External synchronization (FX-75 only)

FX-75 is incorporated with the trigger function, either gate or edge trigger is available.

With only a synchronizing sensor directly connected to FX-75, the synchronous detection is realized without any other controller.

<For IC orientation detection>



OFF-delay timer (FX-7 & FX-77 only)

Each of the FX-7 and the FX-77 is incorporated with the OFF-delay timer, for approx. 40 ms fixed.

It is useful when the output signals are so quick and short that a connected device can not take in, for example, by slow scanning time of a device or miniature object detection on a fast production line.



Wafer in vacuum chamber

The vacuum fiber kit composed of the inner fiber, the joint fiber, and the outer fiber detects a wafer inside a vacuum chamber with air-tightness.



Presence of glass substrate

The FD-L41 securely detects the nearest glass substrate only.



Test input (emission halt input) (FX-75 only)

FX-75 is incorporated with the test input (emission halt input) that makes beam emission stop. It is useful to check for the operability before start-up. <When using thru-beam fiber>



Remote sensitivity adjustment (FX-77 only)

Distinguishing top / bottom surface

Due to the small spot size, the top

surface can be distinguished from the

bottom surface for small components,

The FD-AFM2E array fiber accurately

detects a seam on a can because of

FD-AFM2E

of a chip component

such as the 1005 chip. FD-G4

FX-MR1

Seam on can

its line focusing.

As the sensitivity can be set with two remote switches from the amplifier, your production change-over becomes smooth.



Plug-in connector type

The FX-7 amplifier with the plug-in connector on the tail can be connected with the SL-BM or the SL-BX of the sensor & wire-saving link system S-LINK; the SL-BMW or the SL-BW of the sensor block for simple wiring; or the CN-54-C2 or the CN-54-C5 mating cable at a touch.

Refer to the details of the S-LINK system on p.1030~, the sensor block for simple wiring on p.882~.



Ramco Innovations - 1207 Maple Street, West Des Moines IA USA 50265 - 800-280-6933 - www.ramcoinnovations.com

1065 *∕∕*אע

FX-7

Genera	General purpose fibers [Thru-beam type (one pair of two fibers a set)]												
Туре	Shape of fiber head (mm)	Sensing range (Note 1) : Red LED type : Green LED type	Min. sensing object [under the optimum condition (Note 2)] [] : Red LED type [] : Green LED type	Features	Fiber cable length	Model No.							
Long sensing range	Lens applicable	600 mm	 \$\overline{0}\$ \$\phi\$ 0.16 mm opaque object \$\overline{0}\$ \$\phi\$ 0.16 mm opaque object 	Twice longer sensing range than before	Free Cut 2 m	FT-B8							
dard	Lens applicable					FT-FM2							
Stan	With sleeve 44	25 mm	 <i>ϕ</i> 0.08 mm opaque object <i>ϕ</i> 0.08 mm opaque object 	Free-cut type	Free Cut 2 m	FT-FM2S With sleeve 90 mm FT-FM2S4 With sleeve 40 mm							
	¢2.5 ←					FT-SFM2							
Small fiber head	Lens applicable M3	320 mm	 (i) ≠0.08 mm opaque object (ii) ≠0.08 mm opaque object 	Miniature but the same sensing range as the standard type	Free Cut 2 m	FT-T80							
eter	M3 ← ⊏ ∎∭)					FT-NFM2							
diame	With sleeve M3	80 mm	() $\phi 0.05$ mm opaque object	Mountable in a tight area or a narrow space	Free	FT-NFM2S With sleeve 90 mm							
Small	¢0.88			• Free-cut type	2 m	With sleeve 40 mm							
	Lens applicable	25 mm	 <i>ϕ</i> 0.08 mm opaque object <i>ϕ</i> 0.08 mm opaque object 		Free Cut	FT-P80							
Flexible	Small diameter M3	100 mm	 (a) φ 0.05 mm opaque object (b) φ 0.08 mm opaque object 	Allowable bending radius: R4 mm or more Bending durability: One million times or more	2 m	FT-P40							
	Small diameter	120 mm	 <i>ϕ</i> 0.08 mm opaque object <i>ϕ</i> 0.08 mm opaque object 		1 m	FT-P2 (Note 3)							

Environment resistant fibers [Thru-beam type (one pair of two fibers a set)]

Min. sensing object Sensing range (Note 1) Fiber cable Vote 2) Туре Shape of fiber head (mm) ■ : Red LED type Features Model No. Red LED type Green LED type length □ : Green LED type M4 ■ Lens applicable FT-H35-M2 Heat-resistant: 350 °C
Cold-resistant: -60 °C 2 m With sleeve M4 ∳2.1 270 mm FT-H35-M2S6 With sleeve 60 mm Heat-resistant Ø 0.12 mm opaque object 20 mm € ¢0.08 mm opaque object · Flexible cable with silicone jacket Lens applicable Heat-resistant: 200 °C 1 m FT-H20-M1 Cold-resistant: - 60 °C ← **□** • Heat-resistant: 130 °C • Cold-resistant: - 60 °C Free Cut 2 m 320 mm Ø 0.12 mm opaque object FT-H13-FM2 37 mm € ¢0.12 mm opaque object Free-cut type φ5.5 Applicable in chemical solvent Chemical-resistant 💃 1,500 mm Image: Image Heat-resistant specification (115 °C) FT-L8Y 2 m Long sensing range with lenses (Bending R:) 30 mm φ5.5 Applicable in chemical solven 300 mm Heat-resistant specification (115 °C) FT-V8Y Side-view type 1 m Lens applicable 200 mm FT-6V Ø 0.1 mm opaque object Bending R: Vacuum Applicable in vacuum 200 mm chamber Heat-resistant: 120 °C 1 m 100 mm FT-60V (Bending R: 30 mm

→■∰⊅

Notes: 1) The free-cut fibers may reduce the sensing ranges 20 % lower than the above specified according to how they are cut off.

2) The optimum condition is specified that the sensitivity is adjusted to have the operation indicator exactly light up at a certain distance in the Light-ON mode.

3) Its model No. has been changed because the shorter plug attachments are provided for the FX-7 connection. The specifications including the sensing range are identical as before.

The vacuum fiber must be used with both the followings.

FT-J6 : Fiber at atmospheric side (one pair of two fibers a set)

FV-BR1: Photo-terminal (one pair of two joints a set)

Specia	l use fibers [Thru-beam ty	pe (one pair of two fit	pers a set)]		r	
Туре	Shape of fiber head (mm)	Sensing range (Note 1) : Red LED type : Green LED type	Min. sensing object [under the optimum condition (Note 2)] [: Red LED type : Green LED type	Features	Fiber cable length	Model No.
sensing th lenses		7,000 mm	() $\phi 0.5$ mm opaque object () $\phi 0.5$ mm opaque object	 Large lenses on the tops of the fiber heads expand the sensing range significantly. Fiber cable length 10 m each 	Free Cut 10 m	FT-FM10L
Long s range wi	¢2.5 ← □	600 mm	(1) $\phi 0.1$ mm opaque object (6) $\phi 0.08$ mm opaque object	• Small fiber heads of \$\phi 2.5 mm with lenses expand the sensing range.	Free Cut 2 m	FT-SFM2L
ay	Top sensing	210 mm	Horizontal \$0.05 mm opaque object Vertical \$0.3 mm opaque object Worizontal \$0.03 mm opaque object Vertical \$0.3 mm opaque object	The wide beam stripe detects an object at any place within	Free X Cut	FT-AFM2
Arr	Side sensing	20 mm	Horizontal \$0.05 mm opaque object Vertical \$0.3 mm opaque object Orizontal \$0.03 mm opaque object Vertical \$0.3 mm opaque object	the area.	2 m	FT-AFM2E
Elbow	Lens applicable	210 mm	 (i) ¢ 0.08 mm opaque object (ii) ¢ 0.08 mm opaque object 	• The fiber head is bent at a right angle of 5 mm radius at the neck.	Free Cut 2 m	FT-R80
	Small	85 mm			1 m	FT-V22 (Note 3)
view	0.6 ↓ $\phi 2.5$ Sleeve part can not be bent. ($\phi 2$ for FT-V22)	45 mm		The side-view sensing		FT-V41
Side-	Sleeve part can not be bent. $(\bigoplus_{\tau}^{\underline{1}}) \qquad \phi 1.5 \phi 2.5 \\ \downarrow \qquad \qquad$	120 mm	 <i>ϕ</i> 0.05 mm opaque object <i>ϕ</i> 0.08 mm opaque object 	space.	Free Cut 2 m	FT-SFM2SV2
Narrow beam	$\leftarrow \underbrace{\overset{\phi 1}{\underbrace{\qquad}} M3}_{\text{Sleeve part can not be bent.}}$	120 mm	Ø Ø 0.05 mm opaque object	The narrow beam-opening angle, one-sixth of a conven- tional model, reduces mutual interference.	1 m	FT-KM1S2

Notes: 1) The free-cut fibers may reduce the sensing ranges 20 % lower than the above specified according to how they are cut off.

2) The optimum condition is specified that the sensitivity is adjusted to have the operation indicator exactly light up at a certain distance in the Light-ON mode.

3) Its model No. has been changed because the shorter plug attachments are provided for the FX-7 connection. The specifications including the sensing range are identical as before.

Semi-standard fibers (Custom made per order)

The standard fibers can be modified in fiber cable length or in sleeve length based on your request. Select the fiber cable length (symbolized with \square) or the sleeve length (symbolized with \square) you need from the below table.

Туре	Basic model No.	Fiber cable length (Unit : m)	Sleeve length (Unit : cm)		
Standard of threaded head (Free-cut)	FT-FM 🕁	3, 4, 5, 10, 15, 20, 25, 30			
With sleeve	FT-FM 🕁 -S 🛆	2 (Note), 3, 4, 5, 10, 15, 20, 25, 30	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12		
With large diameter lens	FT-FM 🔂 L	20, 30			
Small diameter of threaded head with sleeve (Free-cut)			1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12		
200 °C heat-resistant FT-H20-M		2, 3			
350 °C heat-resistant	FT-H35-M 🕁	3			

Correlation between sensing range attenuation coefficient and fiber cable length

The longer the fiber cable, the shorter the sensing range.



Note: The standard fiber features 2 m in fiber cable length and 4 cm or 9 cm in sleeve length.

FX-7

Genera	al purpose fibers [Reflectiv	ve type]t				
Туре	Shape of fiber head (mm)	Sensing range (Note 1, 2) : Red LED type : Green LED type	Min. sensing object [at the maximum sensitivity (Note 3)] [: Red LED type : Green LED type	Features	Fiber cable length	Model No.
Long sensing range		160 mm	 <i>ϕ</i>0.01 mm gold wire <i>ϕ</i>0.16 mm copper wire 	Long sensing range	Free Cut 2 m	FD-B8
ıdard	Coaxial ← □			Suitable for green LED type	500 mm	FD-5 (Note 4)
Star		130 mm				FD-FM2
	With sleeve M6 ←□□□□□□□	8 mm		Free-cut type	Free Cut 2 m	FD-FM2S With sleeve 90 mm
	¢2.5 "CLD"					FD-FM2S4 With sleeve 40 mm
ead	← @∰ ™	130 mm	 <i>ϕ</i> 0.01 mm gold wire <i>ϕ</i> 0.4 mm copper wire 	old wire pper wire		FD-T80
all fiber he	Small diameter M3	30 mm 2.5 mm	 <i>φ</i>0.01 mm gold wire <i>φ</i>0.4 mm copper wire 	Miniature but the same sensing range as the standard type	Free Cut 2 m	FD-T40
Sm	¢3 ←	130 mm	 <i>φ</i> 0.01 mm gold wire <i>φ</i> 0.4 mm copper wire 			FD-S80
eter	← ⊂∎ᠿ					FD-NFM2
l diame	With sleeve	30 mm 2 mm	∮ 0.01 mm gold wire ∮ 0.4 mm copper wire	Mountable in a tight area or a narrow space Free-cut type	Free Cut	FD-NFM2S With sleeve 90 mm FD-NFM2S4
Smal	¢2.5 ←					FD-SNFM2
_	← m∰m	80 mm	 \$\phi\$ 0.01 mm gold wire \$\phi\$ 2.1 mm stainless steel bar 		Free Cut	FD-P80
Flexible	Small diameter M3 ← ∰	🔲 8 mm		Anowable bending radius: R4 mm or more Bending durability: One million times or more	2 m	FD-P40
-	Small diameter	15 mm 1 mm	 <i>φ</i>0.01 mm gold wire <i>φ</i>0.4 mm copper wire 		1 m	FD-P2 (Note 4)

Environment resistant fibers [Reflective type]

Туре	Shape of fiber head (mm)	Sensing range (Note 1, 2) : Red LED type : Green LED type	Min. sensing object [at the maximum sensitivity (Note 3)] [] : Red LED type [] : Green LED type	Features	Fiber cable length	Model No.
	Coaxial M6			• Heat-resistant: 350 °C	2 m	FD-H35-M2
t	With sleeve M6	88 mm	$0 \neq 0.01 \text{ mm}$ aold wire	• Cold-resistant: - 60 °C	2 111	FD-H35-M2S6 With sleeve 60 mm
Heat-resistant	Coaxial ← □∭∭ ∃	9 mm		 Flexible cable with silicone jacket Heat-resistant: 200 °C Cold-resistant: - 60 °C 	1 m	FD-H20-M1
	←⊂∭∭	88 mm	 (i) ¢ 0.01 mm gold wire (ii) ¢ 1.45 mm stainless steel bar 	• Heat-resistant: 130 °C • Cold-resistant: — 60 °C • Free-cut type	Free Cut 2 m	FD-H13-FM2
Vacuum	⊷ ∭∭	50 mm		Applicable in vacuum chamber Heat-resistant: 120 °C	1 m	FD-6V

 \square

Notes: 1) The sensing range is specified with using white non-glossy paper (50 × 50 mm). (Standard-Long sensing range: 100 × 100 mm) 2) The free-cut fibers may reduce the sensing ranges 20 % lower than the above specified according to how they are cut off.

3) The minimum sensing object is obtainable with the maximum sensitivity, but at the ideal sensing distance within the rated sensing range.

4) Its model No. has been changed because the shorter plug attachments are provided for the FX-7 connection. The specifications including the sensing range are identical as before.

The vacuum fiber must be used with both the followings.

FT-J6 : Fiber at atmospheric side (one pair of two fibers a set) FV-BR1: Photo-terminal (one pair of two joints a set)

Speci	al use fibers [Reflective typ	e]∎				
Туре	Shape of fiber head (mm)	Sensing range (Note 1, 2) : Red LED type : Green LED type	Min. sensing object [at the maximum sensitivity (Note 3)] [: Red LED type] : Green LED type	Features	Fiber cable length	Model No.
ective		4.5 to 8 mm (Center: 6 mm)		• The optical system cancels affection by color or surface condition of an object.		FD-L4
-focus refl Glass substrate	24×21	3 to 13 mm (Center: 8 mm)		Just 4 mm thick Glass board is securely detected.	Free Cut 2 m	FD-L41
Fixed Water or specular	15×19	Center: 2 mm		Just 3 mm thick Wafer is securely detected.		FD-L42
sion	Lens applicable Coaxial	44 mm		The coaxial fiber gives precise and symmetrical	Free Cut 2 m	FD-G4
ecis				sensing.	500 mm	FD-G500
High pi	Lens applicable M3 Coaxial • Small diameter ← C	13 mm		 The combination with the FX-MR3 lens gives the small spot diameter of approx. \$0.3 mm. 	500 mm	FD-EG1
ray		66 mm	Horizontal ¢0.01 mm gold wire Vertical ¢0.05 mm copper wire	 Its wide and flat detection area enables to detect 	Free Cut	FD-AFM2
Ar	Side sensing	4 mm	G Horizontal ∉0.08 mm copper wire Vertical ∉1.45 mm stainless steel bar	objects traveling through inexactly.	2 m	FD-AFM2E
Elbow		66 mm	 \$\overline{0}\$ \$\phi\$ 0.01 mm gold wire \$\overline{0}\$ \$\phi\$ 2.1 mm stainless steel bar 	• The fiber head is bent at a right angle of 5 mm radius at the neck.	Free Cut 2 m	FD-R80
-view	Small diameter $\phi 1.5$ 0.7 $\phi 3$ Sleeve part can not be bent.	15 mm		.02 mm gold wire • The side view sensing		FD-V41
Side	$ \begin{array}{c} \begin{array}{c} & & & \\ \hline \\ \hline \\ \hline \\ 0.8 \end{array} \end{array} \begin{array}{c} \phi 2 \\ \hline \\ \phi \end{array} \begin{array}{c} \phi 5 \\ \hline \\ \phi \end{array} \end{array} $ Sieeve part can not be bent.	24 mm 2 mm	 \$\vee\$\$\phi\$ 0.02 mm gold wire \$\vee\$	space.	2 m	FD-SFM2SV2
small eter	Sleeve part can not be bent. $M3$	🛾 1.5 mm		Mountable in a complex area	500 mm	FD-EN500S1
Ultra- diam	Coaxial $\phi 0.8$ M3 Sleeve part can not be bent.	13 mm	Ø φ 0.01 mm gold wire	 The coaxial fiber gives precise and symmetrical sensing. 	1 m	FD-ENM1S1
Narrow- view	Coaxial	9 mm		• The narrow beam-opening angle, one-sixth of a conven- tional model, makes a small detecting area.	1 m	FD-KM1S2
tection	¢6	· · · · · · · · · · · · · · · · · · ·	(Liquid)	Liquid drop on the top never affects the sensing.	Free Cut	FD-F8Y
evel det	25×20	Applicable pipe diameter: ϕ 6 to ϕ 26 mm		Liquid surface is securely	Free Cut	FD-F4
Liquid I Mountable		PFA (Fluorine resin) or the equivalent bearing the same transparency thickness 1 mm	(Liquia)	detected from the outside of a pipe.	Free Cut 2 m	FD-F9

Notes: 1) The sensing range is specified with using white non-glossy paper (50 × 50 mm). (Side-view · Small diameter: 30 × 30 mm, Narrow-view: 10 × 10 mm) 2) The free-cut fibers may reduce the sensing ranges 20 % lower than the above specified according to how they are cut off.

3) The minimum sensing object is obtainable with the maximum sensitivity, but at the ideal sensing distance within the rated sensing range.

Semi-standard fibers (Custom made per order)

The standard fibers can be modified in fiber cable length or in sleeve length based on your request. Select the fiber cable length (symbolized with \square) or the sleeve length (symbolized with \square) you need from the below table.

Туре	Basic model No.	Fiber cable length (Unit : m)	Sleeve length (Unit : cm)		
Standard of threaded head (Free-cut)	FD-FM 🕁	3, 4, 5, 10, 15, 20			
With sleeve	FD-FM☆ -S△	2 (Note), 3, 4, 5, 10, 15, 20	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12		
Small diameter of threaded head with sleeve (Free-cut)	FD-NFM2-S		1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12		
200 °C heat-resistant	FD-H20-M 🖾	2, 3			
350 °C heat-resistant	FD-H35-M 🖾	3			

Note: The standard fiber features 2 m in fiber cable length and 4 cm or 9 cm in sleeve length.

Correlation between sensing range attenuation coefficient and fiber cable length



Amplifiers

FX-7

				F	unctions	(•: Inc	orporate	d)			
Туре	Appearance	Model No.	Sensitivity shift	Stability margin indication	External synchro- nization	Test input (emission halt)	Remote sensitivity adjustment	OFF-delay timer	Interference prevention	Emitting element	Output
be		FX-7								Pod I ED	NPN open-collector transistor
rd ty		FX-7P						•	•		PNP open-collector transistor
anda	anda	FX-7G		•						Groop LED	NPN open-collector transistor
Ste		FX-7GP								Gleen LED	PNP open-collector transistor
ernal nization type	ization type	FX-75								Red LED	
Exte synchro input		FX-75G			•	•			•	Green LED	
Remote sensitivity adjustment type	FX-77								Red LED	NPN open-collector transistor	
		FX-77G						•	•	Green LED	

Plug-in connector type

Integrated plug-in connector is available on the standard type. (Standard: Cable type) Model No.: FX-7J, FX-7PJ (Red LED type)

FX-7GJ, FX-7GPJ (Green LED type) Applicable with the SL-BM or the SL-BX of the sensor & wire-saving link system S-LINK; the SL-BMW or the SL-BW of the sensor block for simple wiring; or the CN-54-C2 or the CN-54-C5 mating cable.



Accessories

• MS-DIN-2 (Amplifier mounting bracket) • FX-CT1 (Fiber cutter)

• FX-CT2 (Fiber cutter) • FX-AT10 (\$\$ 1 mm fiber attachment) • FX-AT13 (\$\$\phi\$ 1.3 mm fiber attachment)

OPTION

Designation	Model No.				Description		Protective tube • FTP- • FDP-								
	FTP-500 (0.5 m)	For		FT-B8	FT-P80		A CONTRACT OF A								
	FTP-1000 (1 m)	M4		FT-FM2 FT-FM2S	FT-H13-FM2		Jan Barrowshill								
Protective tube	FTP-1500 (1.5 m)	thread		FT-FM2S4			Fiber bender								
(fiber)	FTP-N500 (0.5 m)	For		FT-T80	FT-P40		• FB-1								
	FTP-N1000 (1 m)	M3	ers	FT-NFM2	FD-T40 FD-P40	The protective	(ST								
	FTP-N1500 (1.5 m)	thread	le fib	FT-NFM2S	4	non-corrosive									
	FDP-500 (0.5 m)	Far	licab	FD-B8	FD-B8 FD-P80										
	FDP-1000 (1 m)	M6	App	FD-FM2 FD-FM2S	FD-H13-FM2	from any stress.	Universal sensor mounting stand • MS-Δ.I1-F								
Protective tube	FDP-1500 (1.5 m)	thread		FD-FM2S4	ļ	-	• MS-AJ2-F								
(For reflective)	FDP-N500 (0.5 m)	5 -1		FD-T80			Using the arm which 360° enables adjustment in rotation								
	FDP-N1000 (1 m)	M4		FD-NFM2	2		the horizontal direc-								
	FDP-N1500 (1.5 m)	thread		FD-NFM2	54		be done from above								
Fiber bender	FB-1	The fibe proper r	r be adiu	nder curves ti s. (Note 1)	ne sleeve part of the fib	er head at the	Height 360° rotation								
Universal sensor	MS-AJ1-F	Horizont	al m	ounting type	Mounting stand assem	bly for fiber	approx.								
mounting stand (Note 2)	MS-AJ2-F	Vertical	mou	nting type	(For M3, M4 or M6 three	eaded head fiber)	Angle adjustment: ± 20° / for M6 screw								
Notes: 1) Do not b	end the sleeve part of any	side-view	fibe	er ultra-small	Angle adjustment: <u>1</u> 20 [°] An										

Notes: 1) Do not bend the sleeve part of any side-view fiber, ultra-small diameter head fiber, or narrow-view fiber. 2) Refer to p.332~ for details of the universal sensor mounting stand.

1070 *รบพX*

Ramco Innovations - 1207 Maple Street, West Des Moines IA USA 50265 - 800-280-6933 - www.ramcoinnovations.com

Note: The above figure is MS-AJ1-F. The mounting base of MS-AJ2-F has a

OPTION

	Designation	Model No.			Description					
				Six times longer	Sensing range (mm) [Two lenses on both sides]					
				or more	Applicable amplifier	Red LED type	Green LED type			
				Ambient temperature: - 60 to + 350 °C	FT-B8	2,500	230			
					FT-FM2	2.000	200			
	Expansion lens	EVIET	0	1	FT-T80	2.000	200			
	(Note 1)				FT-P80	2.000	200			
			() and ()		FT-H35-M2	1,600	140			
					FT-H20-M1	1,600	140			
					FT-R80	1,600	190			
				Tremendously	Sensing range (mm) [Two lenses on l	poth sides]			
				increases the	Applicable amplifier Fiber	Red LED type	Green LED type			
				with large diame-	FT-B8	3,500 (Note 2)	1,400			
			-61	ter lenses.	FT-FM2	3,500 (Note 2, 3)	1,700			
Jer	Super-expansion	EVIES		-60 to + 350 °C	FT-P80	3,500 (Note 2)	1,300			
ці л	(Note 1)				FT-H35-M2	3,500 (Note 2, 4)	800			
beal					FT-H20-M1	1,600 (Note 2)	900			
-nu-			~		FT-H13-FM2	3,500 (Note 2)	800			
or th					FT-R80	3,500 (Note 2)	1,400			
ш										
				Beam axis is bent	Sensing range (mm) [Two lenses on l	both sides]			
				by 90°.	Applicable amplifier	Red LED type	Green LED type			
				Ambient temperature: - 60 to + 300 °C	FT-B8	750	40			
		FX-SV1			FT-FM2	400	35			
	Side-view lens				FT-T80	400	35			
					FT-P80	400	35			
					FT-H35-M2	300	25			
					FT-H20-M1	300	25			
				Six times longer	Sensing range (mm) [Two lenses on both sides]					
	Expansion lens for	FV-LE1	-Ora	Ambient temperature: - 40 to + 120 °C	Applicable amplifier Fiber	Red LE	D type			
	(Note 1)				FT-6V	1,2	00			
					FT-60V	6	00			
				Dippoint apot of 10	Emm Enchlos dotactic	n of minuto objecto o	r amall marka			
	Pinpoint spot lens	FX-MR1	A second	 Applicable amplifi 	ers: Red LED type • [Distance to focal point	$:6\pm1$ mm			
				Applicable fibers:	FD-G4 or FD-G500 • A	mbient temperature:	− 40 to + 70 °C			
			Screw-in	The spot diameter	is adjustable from $\phi 0.7$	to Sensing rang	ge			
	_			 Applicable amplifi 	ers: Red LED type	in depth for	cal point Spot diameter			
	Zoom lens	FX-MR2	Distance to	Applicable fibers:	FD-G4 & FD-G500	7 mm Approx	.18.5 mm			
			focal point	Ambient temperat Accessory: MS-E	K-3 (Mounting bracket)	12 mm Approx	$\frac{1200}{12000}$ $\frac{12000}{12000}$ $\frac{12000}{12000}$			
ē			diameter	,			$\varphi_{2.0}$ mm $\varphi_{2.0}$ mm			
e fib				 Finest spot of \u03c60.3 Applicable amplifi 	8 mm (with FD-EG1) ers: Red I ED type	Sensing rang	ge			
ctiv				Applicable fibers:	FD-EG1 & FD-G4	in depth focal	point Spot diameter			
efle	Finest spot lens	FX-MR3	Distance to focal point	 Ambient temperat 	ure: - 40 to + 70 °C	FD-EG1 7.5±0	$0.5 \text{ mm} \text{ Approx. } \neq 0.3 \text{ mm}$			
			Spot diameter			 FD-G4 /.5±0	7.5 mm Approx. ¢ 0.5 mm			
4			Spot diameter							
			Screw-in	FX-MR2 is convert	ed into a side-view type	and Sensing rang	ge			
				Applicable amplifi	a very small space. ers: Red LED type	Screw- Dis in depth for	stance to cal point Spot diameter			
	Zoom lens			Applicable fibers:	FD-G4 & FD-G500	8 mm Appro	ox.13 mm			
	(Side-view type)	FX-101H5	Distance to focal point	Ambient temperat	ure: - 40 to + 70 °C	10 mm Appro	x.15 mm ∳0.8 mm			
						14 mm Appro	x.30 mm ∳3.0 mm			
			Spot diameter							

Notes: 1) Be careful when installing the thru-beam type fiber equipped with the expansion lens, as the beam envelope becomes narrow and alignment is difficult. Especially when installing a fiber with many cores (heat-resistant glass fiber) please be sure to use it only after you have adjusted it sufficiently. 2) The fiber cable length practically limits the sensing range at 3,500 mm long (**FT-H20-M1**: 1,600 mm). 3) The sensing range can be expanded up to 14.5 m with fiber cables 10 m long each.

4) The sensing range can be expanded up to 5.5 m with fiber cables 3 m each.

SPECIFICATIONS

FX-7

Fibers										
Туре	Standard, Small fiber head, Small diameter, Flexible, Long sensing range with lenses, Array, Elbow, High precision,	Heat-resistant			Chemical- resistant	Vacuum	Fixed-focus reflective	Side-view, Narrow beam, Narrow-view, Reflective of	Liquid level detection	
Item	Thru-beam of ultra-small diameter	350 °C type	200 °C type	130 °C type				diameter		Mountable on pipe
Allowable bending radius	R: (Flexib (Thru-beam of ultra	R30 mm or more	R200 mm or more (FT-60V : (R30 mm or more)	R10 mm or more	R25 mm or more	Protective tube: R40 mm or more Fiber cable: R15 mm or more	R10 mm or more			
Ambient temperature	- 40 to + 70 °C (FD-EG1: − 20 to + 60 °C)	-60 to + 350 ℃ (Note 1, 2)	-60 to +200 ℃ (Note 2)	— 60 to + 130 °C	— 40 to + 115 °C	−40 to + 120 °C	- 40 to + 70 °C (FD-L42 : (-40 to + 60 °C)	- 20 to + 60 °C (FT-V41 , (FD-V41 : - 40 to + 60 °C	-40 to + 125 ℃ (Note 3)	-40 to+100 ℃ (Note 3)

Ambient humidity

35 to 85 %RH (No dew condensation nor icing allowed)

	Fiber core	Acrylic	Multi-componer	nt glass (Note 4)	Acı	ylic	Quartz glass (Note 4)		Acı	rylic	
	Sheath	Polyethylene (Flexible: Vinyl chloride, FD-P2 : Vinyl chloride· polyurethane		Silicone (SUS spiral) (tube inside)	Fluorine resin		Fluorine resin	Polyet (Reflective (view type: F	hylene of narrow- Polyurethane)		Polypropylene
Material	Fiber head	Brass: Threaded part of (Nickel) standard, Threaded part of small diameter, High precision, Threaded part of ultra-small diam- eter, FT-P80, FD-P80, Array, Threaded part of FT/FD-R80 Stainless steel (SUS): FT-SFM2, Small fiber head, FT-SNFM2, FT-SNFM2, FT-SFM2L, FT-SFM2L, FT-P40, FD-P2, Sleeve part of sleeve-attached fiber ABS: FT-FM10L (Lens: Acrylic)	Stainless steel (SUS)	Brass (Nickel plated)	Brass (Nickel plated)	Protective tube: Fluorine resin Fiber sheath: Polypropylene	Aluminum	ABS: FD-L4, FD-L41, (Lens: Acrylic) Aluminum: FD-L42 (Lens: Acrylic)	Stainless steel (SUS) (Threaded part of FD-EN500S1, FD-ENM1S1, FT-KM1S2 and FD-KM1S2: Brass	Protective tube: Fluorine resin Sheath: Polypropylene	Polyetherimido
Accessories		Threaded head fiber: 2 p Free-cut type, chemical- Small diameter of free-c (FD-L41, FD-L42, FD-F4 ED-F4 and ED-F9: 4 pcs	bcs. of nuts (tresistant fibe ut fiber, Fixe and FD-F9 : of tying bar	hru-beam typ r and liquid le d-focus reflec 1 set of atta ods and 2 pc	be: 4 pcs.) ar evel detection ctive fiber, hig chments)	nd 1 pc. of to n fiber: 1 pc. gh precision tubes	othed lock wa of FX-CT2 (F of free-cut fik	tasher (thru-b T-P80, FD-P per, FD-F4 ar	eam type: 2 80: FX-CT1) nd FD-F9: 2	pcs.) (Fiber cutter) sets of plug a	attachments

FD-L4: 2 pcs. of M2.6 \times 12 mm screws with washers and 2 pcs. of nuts

Notes: 1) If the fiber is used under - 30 °C, its resistable maximum temperature drops to + 200 °C. If the side-view lens FX-SV1 is put on the fiber head, the allowable maximum temperature comes down to + 300 °C. (The ambient temperature range of FX-SV1 is from - 60 to + 300 °C.)
2) The ambient temperature of heat-resistant 350 °C type and 200 °C type fibers is the value in dry condition. In humid environment, the ambient temperature differs. (For a high humidity of 85 % RH, the ambient temperature is 0 to + 40 °C.)
3) With the liquid level detection fiber, also make sure of the temperature of the liquid in which the fiber is immersed.
4) Keep the fiber composed of multi-component class or quarts dises from withration or impact.

4) Keep the fiber composed of multi-component glass or quarts glass from vibration or impact.

OTHER SUNX PRODUCTS

SPECIFICATIONS

Amplifiers

	ipiniera									
Туре		NPN output						PNP output		
		Standard ty	pe	External synchro	onization input type	Remote sensitivity	adjustment type	Standar	d type	
Ite	m Model No.	FX-7	-X-7G	FX-75	FX-75G	FX-77	FX-77G	FX-7P	FX-7GP	
Su	pply voltage	12 to 24 V DC ± 10 % Ripple P-P 10 % or less								
Cu	rrent consumption				30 mA	or less		1		
Sei	nsing output	NPN open-collector transistor • Maximum sink current: 100 mA • Applied voltage: 30 V DC or less • Residual voltage: 1.0 V or less (at 100 mA sink current) 0.4 V or less (at 16 mA sink current)					Maximum source current: 100 mA Applied voltage: 30 V DC or less Residual voltage: 2.0 V or less (at 100 mA source current) 1.0 V or less (at 16 mA source current)			
	Utilization category				DC-12 (or DC-13		1		
	Output operation	Selectable either Light-ON or Dark-ON with the order of pressing ON and C (Selectable with the external inputs on the FX-77 or the FX-77G								
	Short-circuit protection				Incorp	orated		1		
Self-diagnosis output		NF	PN open-co • Maximul • Applied • Residua	ollector transisto n sink current: 5 voltage: 30 V D I voltage: 1.0 V 0.4 V	or 50 mA C or less or less (at 50 mA or less (at 16 mA	A sink current) A sink current)		PNP open-collector • Maximum sourc • Applied voltage • Residual voltag (at 50 m (at 16 m	transistor 2e current: 50 mA 30 V DC or less 20 V or less 1A source current) 1.0 V or less nA source current)	
	Output operation	ON under the unsta short-circuited until (The remote sensitiv	ble sensin t is remov vity adjustr	g condition and ed nent type make	it is restored autors it turned ON for	omatically after a r approx. 40 ms a	pprox. 40 ms; a after the remote	also ON if the ser	ising output is is received.)	
	Short-circuit protection									
Re	sponse time		0.5 ms	or less (0.7 ms	or less when the	interference prev	ention function	is used)		
Ор	eration indicator		Red LED (lights up when the sensing output is ON)							
Stability indicator		Green LED ('RUN' mode: Lights up at the stable Light condition or the stable Dark condition 'SET' mode : Blinks twice when the difference between ON and OFF levels is greater than the hysteresis, but 15 times when it is equal to or less than the hysteresis after the completion of the sensitivity setting. Also blinks twice after the interference prevention is set 'SET' mode'SIF' or 'RUN' mode: Blinks from 0 to 5 times according to the operation margin								
Tes	t input (emission halt) function			Incor	porated					
Ext	ernal synchronization function	Incorporated (Either gate or edge) (trigger is selectable)								
Ren	note sensitivity adjustment function					Incorpo	orated			
Se	nsitivity shift function	Shifts the sensitivity setting level								
Inte	erference prevention function	Incorporated								
Tim	ner function	Fixed OFF-delay timer a (switchable either or ineffective	oprox. 40 ms effective			Fixed OFF-delay timer approx. 40 ms (switchable either effective or ineffective)			; ive)	
	Pollution degree				3 (Industrial	environment)				
JCe	Ambient temperature	- 10 to $+$ 50 °C (No dew condensation or icing allowed), Storage: $-$ 20					to + 70 °C			
istar	Ambient humidity			35	to 85 %RH, Sto	rage: 35 to 85 %	RH			
l res	Ambient illuminance	Sun light: 10,000 ℓ x at the light-receiving face, Incandescent light: 3,000 ℓ x at the light-receiving face								
enta	EMC	EN 50081-2, EN 50082-2, EN 60947-5-2								
nme	Voltage withstandability	1,000 V AC for one min. between all supply terminals connected together and enclosure (Note)								
nvird	Insulation resistance	20 MΩ, or r	nore, at 25	50 V DC Megge	V DC Megger between all supply terminals connected togeth				er and enclosure (Note)	
ш	Vibration resistance	10	to 150 Hz	frequency, 0.7	5 mm amplitude,	and X, Y, and Z o	directions for tw	vo hours each		
	Shock resistance	98 m/s ² acceleration (approx. 10 G), and X, Y, and Z directions for five times each								
Em	itting element (modulated)	Red LED Gr	een LED	Red LED	Green LED	Red LED	Green LED	Red LED	Green LED	
Material			Enclosure: Heat-resistant ABS, Case cover: Polycarbonate, Fiber lock lever: PPS							
Ca	ble	0.15 mm	14 6-core c	abtyre cable, 2	m long (FX-7, F	x-7G, FX-7P or F	-X-7GP: four 0	.2 mm ² conductor	'S)	
Ca	ble extension	Extension up to total 100 m is possible with 0.3 mm ² or more, cable.								
We	aght	65 g approx.								
Aco	cessory	MS-DIN-2 (Mounting bracket): 1 pc.								

Note: The voltage withstandability and the insulation resistance described in the above table are inherent in the amplifier only.

FX-7

I/O CIRCUIT AND WIRING DIAGRAMS



PRECAUTIONS FOR PROPER USE

Refer to p.1135~ for general precautions and p.94~ for fiber precautions.

Amplifier



This product is not a safety sensor. Its use is not intended or designed to protect life and prevent body

injury or property damage from dangerous parts of machinery. It is a normal object detection sensor.

Mounting



- 1) Hook the rear part to the attached mounting bracket (MS-DIN-2) or DIN rail.
- 2 Press the amplifier down on the bracket or DIN rail.

DIN rail or the attached mounting bracket

% To remove the amplifier, push it forward and lift up the front side.



How to connect fiber cables

• The set of fiber cables is connected at a touch.



(1) Snap the fiber lock lever down.

FX-7

- 2 Insert both fiber cables into the inlets slowly until fully deepened.
- ③ Snap the fiber lock lever up until a 'click' is heard.

Fiber lock lever

Designation



Note: The external synchronization selection switch is substituted for it on FX-77 or FX-77G.

Amplifier

Sensitivity adjustment

· How to use the sensitivity setting buttons

Normally ON mode that the sensing output is turned ON with an object



Notes: 1) Regardless of the indication that the detection is marginal, setting of the sensitivity can be perfected, but remember it is severe detection.

 Your set sensitivity is stored in the EEPROM memory that has the limited lifetime. The sensitivity allows to be reset until 100,000 times.

Reverse ON mode that the sensing output is turned ON without an object

• Follow the same procedure as the above except for; Press the OFF button with an object placed in front of the fiber.

Press the ON button with the object set aside.

How to obtain the maximum sensitivity

- ① Set the mode selection switch to 'SET'.
- 2 · For the Light-ON operation mode
 - Press the ON button followed by OFF button under the condition that beam is not received (or make the remote sensitivity ON input into Low as well as the OFF input). • For the Dark-ON operation mode
 - Press the OFF button followed by the ON button under the condition that beam is not received (or make the remote sensitivity OFF input into Low as well as the ON input).
- ③ Set the mode selection switch to 'RUN'.
 - <Applications>
 - To obtain the longest sensing range with the reflective fiber.
 - To use the thru-beam fiber in a harsh environment.

Combination with FD-F8Y



- Notes: 1) Regardless of the indication that the detection is marginal, setting of the sensitivity can be perfected, but remember it is severe detection.
 - Your set sensitivity is stored in the EEPROM memory that has the limited lifetime. The sensitivity allows to be reset until 100,000 times.

Combination with FD-F4 or FD-F9

In High-Level-ON mode

Procedure	Sensing condition	Operation
1		Set the mode selection switch to 'SET'.
2	Fiber	Press the OFF button when the level is lower than the position the fiber head is installed.
3		When the sensor accepts it, the stability indicator (green) blinks.
4		Press the ON button when the level is higher than the position the fiber head is installed.
5		 The stability indicator blinks twice when the difference between the ON level and the OFF level is so sufficient as to detect the liquid level securely. The stability indicator blinks continuously if the difference is so diminutive as to detect the liquid level. (Note 1)
6		Set the mode selection switch to 'RUN'. Then, the set sensitivity is registered. Even if the buttons are pressed by mistake under the 'RUN' mode, the registered sensitivity stays unchanged.

Notes: 1) Regardless of the indication that the detection is marginal, setting of the sensitivity can be perfected, but remember it is severe detection.

- In Low-Level-ON mode, press the ON and the OFF buttons in the reverse order of the above procedure.
- Your set sensitivity is stored in the EEPROM memory that has the limited lifetime. The sensitivity allows to be reset until 100,000 times.

FX-7

PRECAUTIONS FOR PROPER USE

Amplifier

Remote sensitivity adjustment

(Remote sensitivity adjustment type only)

The sensitivity adjustment using the remote sensitivity adjustment inputs takes the same procedure as the adjustment using the ON and the OFF buttons. Making the ON and the OFF inputs into Low substitutes for pressing the ON and the OFF buttons respectively.

Note: This function is operable also in RUN mode.



Signal condition

State	Signal condition
High	4.5 to 30 V or Open
Low	0 to 1 V

Input impedance: 10 kΩ

• The self-diagnosis output stays ON for 40 ms approx. after the ON input or the OFF input is recognized by the sensor. (Refer to '• **Time chart**'.)

(If the difference between the ON level and the OFF level is so small as to detect an object, it is not turned ON.)

Time chart

Doworoupply	ON
Power supply	OFF
Remote sensitivity	High
ON input	Low
Remote sensitivity	High
OFF input	Low
Self-diagnosis output	
(Answer back function)	OFF (Note)
Sensing output	Sensing ready

 $T_1 \ge 1,000 \text{ ms}, T_2 \ge 5 \text{ ms}, T_3 \doteqdot 310 \text{ ms}, T_4 \doteqdot 40 \text{ ms}, T_5 \ge 500 \text{ ms}$ Note: Do not change the incident beam intensity during the T_3.

Stability margin indication function

 After your setting sensitivity, the FX-7 amplifier reveals the margin of the stability. Slide the mode selection switch from 'SET' to 'SIF' or 'RUN', and the stability indicator (green) blinks. The number of blinking represents the margin of the stability.

Number of blinks	0	1	2	3	4	5
Margin (%) (Margin near by threshold level)	Under 15	15 to 30	30 to 45	45 to 60	60 to 75	Over 75

The larger margin stability affirms the more secure detection.

Sensitivity shift function

• If either one of the Light state or the Dark state is stationary, and the other is unsteady, the sensitivity shift function is useful to make your sensing secure by shifting the threshold level to the stationary side.

For example, to obtain the maximum sensitivity less than the background level in reflective mode, or minimum sensitivity more than the complete Dark level not to be affected by dirt or dust in thru-beam mode.

Reflective sensing with background

- · Because the sensitivity is set at the maximum not to detect
- a background (the lowest threshold level above the background Dark level), the detection becomes durable and reliable even objects vary in color or reflection ratio, or the fiber head is spoiled.





Setting

Procedure	Operation	
1	Set the sensitivity according to the general method described on the front page.	ıe
2	Set the mode selection switch to 'SIF'.	-
3	Press the sensitivity setting button that has been pressed under the Dark condition there is no object, but only a background. (With the above example, press the OFF button.)	те
4	Set the mode selection switch to 'RUN'. (The sensitivity shift function is perfected.)	•

Note: The sensitivity shift function can not be effected by the remote sensitivity adjustment inputs on FX-77 or FX-77G.

Limit sensitivity to detect minute object in thru-beam type

• It is useful to detect a tiny object like a fine thread with the thru-beam fiber. Any object is not needed to set the sensitivity.

Settir	g	
Procedure	Operation	
1	Set the mode selection switch to 'SET'.	_
2	Press the OFF button (or the ON button) in the complete Light state. (There is no object between fiber heads.)	
3	Press the ON button (or the OFF button) in the complete Dark state. (Shield the light-receiving part not to receive the beam.)	
4	Set the mode selection switch to 'SIF'.	_
5	Press the button again that has been pressed in the Light state.	
6	Set the mode selection switch to 'RUN'	F

Notes: 1) If your object can not be detected by the above sensitivity setting, try the general sensitivity setting with using the object or replace the set of the fiber cables with the small diameter fiber.

The sensitivity shift function cannot be effected by the remote sensitivity adjustment inputs on FX-77 or FX-77G.

PRECAUTIONS FOR PROPER USE

Amplifier

FX-7

Thru-beam sensing in harsh environment

 Because the sensitivity is set at the maximum not to be affected by dirt or dust (the

lowest threshold level above the Dark level), the detection becomes durable and reliable over the beam intensity comes down by dirt or dust.



Setting

Procedure	Operation
1	Set the sensitivity according to the general method described on the front page.
2	Set the mode selection switch to 'SIF'.
3	Press the sensitivity setting button that has been pressed under the Dark condition there is an object between the fiber heads. (With the above example, press the ON button.)
4	Set the mode selection switch to 'RUN'. (The sensitivity shift function is perfected.) ● RUN ← ● SIF ● SET

Note: The sensitivity shift function cannot be effected by the remote sensitivity adjustment inputs on FX-77 or FX-77G.

Self-diagnosis function

 The sensor diagnosis itself in the incident beam intensity. If the lens is foiled with dirt or dust, or the beam alignment is displaced, the output is generated.



- The self-diagnosis output transistor stays in the 'OFF' state during the stable sensing.
- ② If the incident beam intensity does not reach the stable Light or Dark level, the self-diagnosis output is turned ON at the same time as the sensor goes from the Light state to the Dark state. It is automatically restored after 40 ms approx.
- (The sensing output does not relate to it.)
- ③ The incomplete Light state introduces to generate the self-diagnosis output at the same time as the sensor changes the states.

However, the incomplete Dark state introduces to generate the self-diagnosis output half-cycle behind.

Interference prevention function

 Every FX-7 amplifier is incorporated with the Interference prevention function. Two sensors operating with the distinct frequencies occur no mutual-interference. Their fiber heads can be mounted close together or face to face.

Setting

Procedure	Operation	
1	Set the mode selection switch to 'SET'.	● RUN ● SIF ● DSET
2	Press both the 'ON' and the 'OFF' buttons simultaneously for 2 sec. or more. [The stability indicator (green) blinks.]	No. Contraction of the second
3	Press the 'ON' button. (The stability indicator blinks twice.) [Response time: 0.5 ms or less (Note 1)]	10 0 × × ×
4	Set the mode selection switch to 'RUN'. (The first ends)	●■RUN ◀─ ● SIF ● SET
(5)	Do the step 1 and 2 on the other sensor.	
6	Press the 'OFF' button. (The stability indicator blinks twice.) [Response time: 0.7 ms or less (Note)]	*****
7	Set the mode selection switch to 'RUN'. (The second ends)	● TRUN ◀─ ● SIF ● SET

Cancel

Procedure	Operation
1	Press both the 'ON' and the 'OFF' buttons simultaneously for the 2 sec.or more. [The stability indicator (green) blinks.]
2	Press both the 'ON' and the 'OFF' buttons again. (The stability indicator blinks twice, then canceled.)

Note: The Interference prevention function enlarges the hysteresis and prolongs the response time. After it is set, the operability must be checked.

OFF-delay timer function

• Every amplifier in the series except for **FX-75** and **FX-75G** is incorporated with the OFF-delay timer fixed for 40 ms approx. The timer function is useful if the output signal responds so quickly that a connected device cannot take in.

To bring the timer in effect, set the timer operation mode switch to 'OFD'.

<Time chart>



Amplifier

External synchronization function (FX-75 and FX-75G only) • The external synchronization function controls the timing

to sense. The edge trigger or the gate trigger is available.



 $T \ge 0.5$ ms ($T \ge 0.7$ ms when the Interference prevention function is used)

Note: To disable external synchronization, set the external synchronization selection switch to 'Gate trigger' side and open the external synchronization input (from 0 V).

Test input (emission halt) function (FX-75 or FX-75G only)

• When the test input (emission halt) function is shortcircuited to 0 V (Low), the beam emission is halted. This function is useful for your start-up test of the sensor operability with no object existing.



• Close and open the input to 0 V repeatedly. If the sensing output responds it, the sensor is well operable. If not, the sensor is in an ill condition.



Wiring

Π

Г

• The **FX-7** series does not incorporate a short-circuit protection at the self-diagnosis output. Do not connect it directly to a power supply or a capacitive load.

Others

The transient time duration is 0.5 sec. after power-up.

DIMENSIONS (Unit : mm) The CAD data in the dimensions can be downloaded from the SUNX website: http://www.sunx.co.jp/ Refer to p.103~ for fiber dimensions.



Note: It is substituted with the external synchronization selection switch on FX-77 or FX-77G.



Material: Cold rolled carbon steel (SPCC)(Uni-chrome plated)