Autonics

Observe all 'Safety Considerations' for safe and proper operation to avoid hazards.

- Δ symbol indicates caution due to special circumstances in which hazards may occur.
- **Warning** Failure to follow instructions may result in serious injury or death.
- 01. Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss. (e.g. nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime/disaster prevention devices, etc.) Failure to follow this instruction may result in personal injury, economic loss or fire.
 - 02. Do not use the unit in the place where flammable/explosive/corrosive gas, high humidity, direct sunlight, radiant heat, vibration, impact, or salinity may be present.
 - Failure to follow this instruction may result in explosion or fire. **03. Do not disassemble or modify the unit.** Failure to follow this instruction may result in fire.
 - Do not connect, repair, or inspect the unit while connected to a power source.
 - Failure to follow this instruction may result in fire. **05. Check 'Connections' before wiring.** Failure to follow this instruction may result in fire.

Caution Failure to follow instructions may result in injury or product damage.

01. Use the unit within the rated specifications.

Failure to follow this instruction may result in fire or product damage. **02.** Use a dry cloth to clean the unit, and do not use water or organic solvent. Failure to follow this instruction may result in fire.

Cautions during Use

Safety Considerations

- Follow instructions in 'Cautions during Use'. Otherwise, it may cause unexpected accidents.
- 12-24 VDC power supply should be insulated and limited voltage/current or Class 2, SELV power supply device.
- Use the product, after 0.8 sec of supplying power.
- Wire as short as possible and keep away from high voltage lines or power lines, to
 prevent surge and inductive noise. Do not use near the equipment which generates
 strong magnetic force or high frequency noise (transceiver, etc.).
 In case installing the product near the equipment which generates strong surge (motor,
 welding machine, etc.), use diode or varistor to remove surge.
- This unit may be used in the following environments.
 Indoors (in the environment condition rated in 'Specifications')
- Indoors (in the environment condition rated in Specifications
 Altitude max. 2,000 m
 Pollution degree 2
- Installation category II

Cautions for Installation

- Install the unit correctly with the usage environment, location, and the designated specifications.
- Do NOT impacts with a hard object or excessive bending of the wire lead-out. It may cause damage the water resistance.
- Do NOT pull the Ø 2.5 mm cable with a tensile strength of 20 N, the Ø 4 mm cable with a tensile strength of 30 N or over and the Ø 5 mm cable with a tensile strength of 50 N or over. It may result in fire due to the broken wire.
- When extending wire, use AWG 22 cable or over within 200 m.
 Refer to the table below for the screw tightening torque when mounting the bracket.

	PSN17	PSN25	PSN30	PSN40
Tightening torque	0.49 N m	0.98 N m	0.98 N m	0.98 N m

Rectangular Inductive Proximity Sensors



PSN Series (DC 3-wire)

PRODUCT MANUAL

For your safety, read and follow the considerations written in the instruction manual, other manuals and Autonics website.

The specifications, dimensions, etc. are subject to change without notice for product improvement. Some models may be discontinued without notice.

Major Features

- Excellent noise immunity with specialized sensor IC
- Built-in surge protection circuit, output short over current protection circuit, reverse polarity protection
- Simple operation, reliable performance, and high durability
- Alternate frequency models allow adjacent installation of multiple sensors without interference (PSN17- \Box -F model)
- Operation indicator (red LED)
- IP67 protection structure (IEC standard)

Ordering Information

This is only for reference.

For selecting the specific model, follow the Autonics web site.

PSN	0	-	2	D	3	4	-	5	
O Sensi	ng side	length	l		09	Sensing	; side		

No-mark: Standard type

No-mark: Standard type F: Differential frequency type

U: Upper side type G Frequency

Number: Side length of head (unit: mm)

Sensing distance

Number: Sensing distance (unit: mm)

Control output


N: NPN Normally Open N2: NPN Normally Closed P: PNP Normally Open P2: PNP Normally Closed


Product Components

	PSN17	PSN25	PSN30	PSN40
Bracket	$1 \times$	$1 \times$	$1 \times$	$1 \times$
Bolt	M3 × 2	$M4 \times 2$	$M4 \times 2$	M5 × 2


Connections

Cable type






Inner circuit (NPN output)



Onevetien Timing Chart



Operation Timing Chart						
		Normally open Normal	ly closed			
Sensing	target	Presence Presen	ce			
Jensing	target	Nothing Nothing Nothing	ng L_ L_			
Load		Operation Operatio				
Load		Return — Retu	m L L I			
	NPN					
Output						
voltage	PNP					
	output					
Operatio						
indicato	or (red)	OFF OF	FF L L L			

Specifications							
Installation	Standard type / Upper side type Standard type						
Model	Model		PSN25- 5D	PSN30- 10D	PSN30- 15D	PSN40- 20D	
Sensing side length	18 mm	18 mm	25 mm	30 mm	30 mm	40 mm	
Sensing distance	5 mm	8 mm	5 mm	10 mm	15 mm	20 mm	
Setting distance	0 to 3.5 mm	0 to 5 mm	0 to 3.5 mm	0 to 7 mm	0 to 10.5 mm	0 to 14 mm	
Hysteresis	\leq 10 % of	\leq 10 % of sensing distance					
Standard sensing target: iron	18 × 18 × 1 mm	25 × 25 × 1 mm	25 × 25 × 1 mm	30 × 30 × 1 mm	45 × 45 × 1 mm	60 × 60 × 1 mm	
Response frequency ⁰¹⁾	700 Hz	200 Hz	300 Hz	250 Hz	200 Hz	100 Hz	
Affection by temperature	\pm 10 % for sensing distance at ambient temperature 20 °C						
Indicator	Operation i	ndicator (rec	4)				
Approval	C€ ERE	C€ ERE	C€ ERE	C€ ERE	C€ ERE	C€ ERE	
Unit weight (package)	≈ 62 g (≈ 83 g)	≈ 62 g (≈ 83 g)	≈ 71 g (≈ 103 g)	≈ 96 g (≈ 165 g)	≈ 96 g (≈ 165 g)	≈ 135 g (≈ 225 g)	
01) The response frequency is the average value. The standard sensing target is used and the width is set as 2 times of the standard sensing target, 1/2 of the sensing distance for the distance.							
Power supply	Power supply 12-24 VDC= (ripple P-P: ≤ 10 %), operating voltage: 10-30 VDC=						


Power supply	12-24 VDC== (ripple P-P: \leq 10 %), operating voltage: 10-30 VDC==		
Current consumption	\leq 10 mA		
Control output	\leq 200 mA		
Residual voltage	$\leq 1.5 \text{V}$		
Protection circuit	Surge protection circuit, output short over current protection circuit, reverse polarity protection		
Insulation type	\geq 50 M Ω (500 VDC= megger)		
Dielectric strength	1,500 VAC \sim 50/60 Hz for 1 min (between all terminals and case)		
Vibration	1 mm amplitude at frequency 10 to 55 Hz (for 1 min) in each X, Y, Z direction for 2 hours		
Shock	500 m/s² (\approx 50 G) in each X, Y, Z direction for 3 times		
Ambient temp.	-25 to 70 °C, storage: -30 to 80 °C (non-freezing or non-condensation)		
Ambient humi.	35 to 95 %RH, storage: 35 to 95 %RH (non-freezing or non- condensation)		
Protection structure	IP67 (IEC standards)		
Connection	Cable type model		
Wire spec.	Ø 4 mm, 3-wire, 2 m		
Connector spec.	AWG 22 (0.08 mm, 60-wire), insulator diameter: Ø 1.25 mm		
Material	Case: Heat-resistant ABS, standard type cable (black): polyvinyl chloride (PVC)		


Dimensions

• Unit: mm, For the detailed dimensions of the product, follow the Autonics web site. A Operation indicator (red) B Tap hole


 ∞


12.3







Standard type / Upper side type






Standard type





25





Standard type

Setting Distance Formula

Sensing target : Up-Down movement Sensing target : Right-Left movement Detecting distance can be changed by the shape, size or material of the ¢œ. target. çedi Sa Sn Sa Sn For stable sensing, install the unit within the 70% of sensing distance. Setting distance (Sa) 0 0 = Sensing distance (Sn) × 70%


Mutual-interference & Influence by Surrounding Metals

Mutual-interference

When plural proximity sensors are mounted in a close row, malfunction of sensor may be caused due to mutual interference.

Therefore, be sure to provide a minimum distance between the two sensors, as below table.

[Face to Face]






0.00 8

4

Differential frequency

When the several proximity sensors are installed closely each other, install standard type and differential frequency type sensors alternativamently to prevent mutual interference due to frequency interference.




Influence by surrounding metals

When sensors are mounted on metallic panel, it must be prevented sensors from being affected by any metallic object except target. Therefore, be sure to provide a minimum distance as below chart.


Standard type

• Upper side type




						(unit: mm)
Model Item	PSN17-5	PSN17-8	PSN25	PSN30-10	PSN30-15	PSN40
Α	30	48	30	60	90	120
В	36	40	40	50	65	70
с	4	4	4	5	5	5
d	15	24	15	30	45	60
m	18	20	20	25	35	35

Sensing Distance Feature Data by Target Material and Size




10 12 15 18 20 25 30 35 40 45 50 60 70 75 80 90 100


One side length of sensing target d (mm)





Sensing Distance Feature Data by Parallel (Left/Right) Movement

• PSN25









----: PSN30-10

